



DNC Precision

See It in Action!

PRINTED MANUAL

DNC Precision

© 2004-2020 AGG Software

All rights reserved. No parts of this work may be reproduced in any form or by any means - graphic, electronic, or mechanical, including photocopying, recording, taping, or information storage and retrieval systems - without the written permission of the publisher.

Products that are referred to in this document may be either trademarks and/or registered trademarks of the respective owners. The publisher and the author make no claim to these trademarks.

While every precaution has been taken in the preparation of this document, the publisher and the author assume no responsibility for errors or omissions, or for damages resulting from the use of information contained in this document or from the use of programs and source code that may accompany it. In no event shall the publisher and the author be liable for any loss of profit or any other commercial damage caused or alleged to have been caused directly or indirectly by this document.

Printed: September 2020

Publisher

AGG Software

Production

© 2004-2020 AGG Software

<http://www.aggsoft.com>

Table of Contents

Part 1 Introduction	1
1 About software	1
2 Glossary	1
Part 2 License, Registration and technical support	3
1 License	3
2 Limitations	5
3 How to acquire a license	5
4 Support	5
Part 3 Installation	6
1 System requirements	6
2 Installation process	6
Part 4 Configuration	6
1 Introduction	6
2 Machine configuration	8
Port parameters	8
Data flow control	10
Logging	11
Program format	12
Characters translation	15
Delays	17
Manual mode	18
Variables	21
Server mode	23
Settings	23
File list	28
Reports	31
Tool break command.....	32
Machine monitor	38
Settings	38
Additional options.....	41
Export monitor data.....	43
Real world example.....	44
3 Windows 2000+ service	45
Part 5 Sending files from other applications	48
Part 6 Troobleshooting	49

II

DNC Precision

1 No data received on CNC side 49

2 No data received on DNC server side 50

3 Garbled data received 50

4 Data received as one long line 51

1 Introduction

1.1 About software

DNC Precision is a communications program specially developed to exchange data and programs between a computer and any Numerical Control (NC) machine. The program makes it possible to send and receive programs written in the machine language. DNC Precision can run on any computer working under Windows 9x, Me, NT, 2000, XP or Windows 2003 Server.

This program can send and receive files both in the manual mode (under the control of the PC user) and automatically by receiving certain requests from the NC.

Main program features:

1. Working with several machines at a time if the system is built according to the radial scheme where each machine is connected to a separate serial port;
2. Creating separate configurations for several machines
 1. Configuring port parameters
 2. Using software or hardware handshaking
 3. Configuring the format of files that are sent and received
 4. Restricting users' access to the program settings
 5. Choosing a separate folder with programs for each machine
3. Creating back-ups
4. Working in the automatic mode when files are sent and received automatically
5. Processing commands transmitted in the header of a data block (only for machines supporting this feature)

Before you go on reading this guide, make sure you are well acquainted with the basic conceptions of the Windows operating system, such as:

- Launching programs.
- Managing windows.
- Managing files (saving, deleting, opening, etc.).
- Using folders and directories.

Company home page: <http://www.aggsoft.com/>

Software home page: <http://www.aggsoft.com/dnc-precision.htm>

Serial port hardware reference: <http://www.aggsoft.com/rs232-pinout-cable/>

1.2 Glossary

Baud Rate - The transmission speed of data through an asynchronous channel. Often confused with BPS (bits per second), baud rate actually refers to the number of signals per second. Because each signal can represent more than one bit of data, the number of bits per second is usually higher than the baud rate. For example, 2400 bps is typically sent at a rate of 600 baud.

Binary File - A file that contains data or program instructions written in ASCII and extended ASCII characters.

ASCII - An acronym for American Standard Code for Information Interchange. ASCII files are plain, unformatted text files that are understood by virtually any computer. Windows Notepad and virtually any word processor can read and create ASCII files. ASCII files usually have the extension .TXT (e.g., README.TXT).

Bytes - A collection of eight bits that represent a character, letter or punctuation mark.

COM port - Short for a serial communication port. Most DNC software communicate with a computer through a communication port, and most IBM and IBM-compatible computers support up to four serial ports COM1, COM2, COM3 and COM4. Additional ports can be added by adding additional hardware.

CNC - Computerized Numerical Control Refers to machine tools that have a computer and memory to control their operation. Most all non manual machine tools sold today will be CNC. see also NC.

Data bits - A group of bits (1's and 0's) that represent a single character or byte. Typically, there are seven or eight data bits. During an asynchronous communication (e.g., BitCom connecting to CompuServe), each side must agree on the number of data bits. Data bits are preceded by a start bit and followed by an optional parity bit and one or more stop bits.

DNC - Acronym that can mean Distributed Numerical Control or Direct Numerical Control depending upon the application. In the beginning DNC stood for Direct Numerical Control. A computer provided machine instructions for a NC milling machine that were transmitted over telephone lines. Later the term DNC evolved to mean a system where a group of CNC machines are linked to a central computer. Or conversely a combination of computers are each linked to one or more CNC machines and the computers are linked together by way of a local area network. Distributed Numerical Control where by NC programs are sent (distributed) to the memory of a CNC machine. The program is then run from the CNC memory.

Flow control - A method of controlling the amount of data that two devices exchange. In data communications, flow control prevents one modem from "flooding" the other with data. If data comes in faster than it can be processed, the receiving side stores the data in a buffer. When the buffer is nearly full, the receiving side signals the sending side to stop until the buffer has space again. Between hardware (such as your modem and your computer), hardware flow control is used; between modems, software flow control is used.

Handshaking - Is the way in which the data flow between computers/hardware is regulated and controlled. Two distinct kinds of handshaking are described: Software Handshaking and Hardware Handshaking. An important distinction between the kinds of signals of the interface is between data signals and control signals. Data signals are simply the pins which actually transmit and receive the characters, while control signals are everything else.

NC - Numerical Control The operation of a machine by a series of coded instruction's that consist of numbers and letters of the alphabet and other symbols. These are translated into pulses of electrical current or other output signals that active motors and other device to run the machine. On early NC machines these signals was often delivered to the machines by using punched tape. Also, the term NC machine refers to machine tools that do not have a computer and memory installed. see also CNC.

NC File – a file containing one or more programs in the special language for Numeric Control machines.

NC Program – a set of instructions written in the machine language and saved to an NC file.

Parity - In data communications, parity is a simple procedure of checking the integrity of transmitted data. The most common type of parity is Even, in which the number of 1's in a byte of data add up to an even number, and None, in which a parity bit is not added.

PC - abbreviation for a Personal Computer.

Punch - CNC output device - used in CNC machines to output programs to perforated tape. Units can be parallel to tape punch or serial output.

RS232, RS423, RS422 AND RS485 - The Electronics Industry Association (EIA) has produced standards for RS232, RS423, RS422, and RS485 that deal with data communications. EIA standards were previously marked with the prefix "RS" to indicate the recommended standard. Presently, the standards are now generally indicated as "EIA" standards to identify the standards organization.

Electronic data communications will generally fall into two broad categories: single-ended and differential. RS232 (single-ended) was introduced in 1962. RS232 has remained widely used, especially with CNC control builders. The specification allows for data transmission from one transmitter to one receiver at relatively slow data rates (up to 20K bits/second) and short distances (up to 50' @ the maximum data rate). This 50' limitation can usually be exceeded to distances of 200' or more by using low capacitance cable and keeping the data rates down to 9600 baud and lower.

RTS/CTS Hardware handshaking - uses additional wires to tell a sending device when to stop or start sending data. DTR and RTS refer to these Hardware handshaking lines. you can select whether you need to use DTR or RTS individually, or use both lines for hardware handshaking. See also Xon/Xoff.

Stop bits - In data communication, one or two bits used to mark the end of a byte (or character). At least one stop bit is always sent.

Upload - To send one or more files from your computer's disk storage to a remote computer. In DNC this usually means from the CNC machine's control back to the DNC computer. This can also mean from your computer's disk to a remote computer, such as another PC or an online service or the internet.

2 License, Registration and technical support

2.1 License

Copyright © 1999-2020 AGG Software.
All Rights Reserved

SOFTWARE LICENSE

Trial Limited Version

The trial limited version of this software may be used for evaluation purposes at the user's own risk for a trial period. At the end of the trial period, the user must either purchase a license to continue using the software or remove it from his/her system.

The trial limited version may be freely distributed, provided the distribution package is not modified. No person or company may charge a fee for the distribution of DNC Precision without written permission from the copyright holder.

Licensed Version

On payment of the appropriate license fee, the user is granted a non-exclusive license to use DNC Precision on one computer (i.e. a single CPU), for any legal purpose, at a time. The registered software may not be rented or leased but may be permanently transferred, if the person receiving it agrees to terms of this license. If the software is an update, the transfer must include the update and all previous versions.

Registered customers are entitled to free updates during one year from the date of purchase. It means that for one year you can download and install the latest registered versions of DNC Precision from our site. If you don't want to purchase an update, you can use the program forever; it will never expire, but you won't be able to use the latest version. If you purchased the software more than one year ago, you are no longer entitled to free upgrade and technical support; however, you can purchase an update to the latest version at a special, greatly discounted price, and this update will allow you to have free updates and technical support for another year. The type of the update license must match the type of your existing license.

Whilst every care has been taken in the construction and testing of this software, it is supplied subject to the condition that the user undertakes to evaluate the suitability of the control for his/her purposes. AGG Software makes no representation of the software's suitability for any purpose, and the user agrees that AGG Software has no responsibility for any loss or damage occasioned by the use of this software.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THE SOFTWARE AND DOCUMENTATION ARE PROVIDED "AS IS" AND AGG SOFTWARE DISCLAIMS ALL OTHER WARRANTIES AND CONDITIONS, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, CONFORMANCE WITH DESCRIPTION, TITLE AND NON-INFRINGEMENT OF THIRD-PARTY RIGHTS.

TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, IN NO EVENT SHALL AGG SOFTWARE BE LIABLE FOR ANY INDIRECT, INCIDENTAL, CONSEQUENTIAL, SPECIAL OR EXEMPLARY DAMAGES OR LOST PROFITS WHATSOEVER (INCLUDING, WITHOUT LIMITATION, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, LOSS OF BUSINESS INFORMATION, OR ANY OTHER PECUNIARY LOSS) ARISING OUT OF THE USE OR INABILITY TO USE THE SOFTWARE PRODUCT, EVEN IF AGG SOFTWARE HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN ANY CASE, AGG SOFTWARE'S CUMULATIVE AND ENTIRE LIABILITY TO YOU OR ANY OTHER PARTY FOR ANY LOSS OR DAMAGES RESULTING FROM ANY CLAIMS, DEMANDS OR ACTIONS ARISING OUT OF OR

RELATING TO THIS AGREEMENT SHALL NOT EXCEED THE PURCHASE PRICE PAID FOR THIS LICENSE.

Should any term of these terms and conditions be declared void or unenforceable by any court of competent jurisdiction, such declaration shall have no effect on the remaining terms hereof.

If you do not agree to these conditions you should not install this software.

2.2 Limitations

The unlicensed program works in the trial mode. The program allows to test all features, but it limits the time and/or amount of processed data. The license key removes all limitations from the trial version. You may purchase a license key [here](#).

The trial version of our software has the following limitations:

- The trial period is limited to 21 days. After that time, the program stops working.
- The continuous program work time is limited to two hours. After that period the program shows a message and stops working;
- All data export modules can handle the first 100 records only;

2.3 How to acquire a license

The unlicensed program works in the trial mode. The license key removes all limitations from the trial version and allows you to use our technical support for one year.

If you want to buy a program through the Internet, visit the [order page](#) of our site. On this page, you can get the newest information about the registration process, and also find an order link. Please, follow the “Buy now” link, enter your personal information, and choose the most convenient payment method for you. Further, you will get a notification and follow the notes in it.

You may find more information about our policies, payment terms, payment methods, and frequently asked questions on our [web site](#).

2.4 Support

Technical questions	support@aggsoft.com
Common questions	info@aggsoft.com
Sales questions	sales@aggsoft.com

3 Installation

3.1 System requirements

Windows 2000 Professional - Windows 10 (2019), including x64 and x86 OS, Workstation, and Server OS.

3.2 Installation process

If any beta-version was installed on your computer, remove it.

Quit of the working DNC Precision on installation time.

Run an installation file.

By default, the installation wizard installs DNC Precision to "C:\Programs Files\DNC Precision" or "C:\Programs Files (x86)\DNC Precision" the directory of your system disk, but you can change this path.

In the standard distributive of DNC Precision are no additional modules files, which you can download from our [site](#).

4 Configuration

4.1 Introduction

To enter the program configuration mode, execute the file "DNCprecise.exe". If the program is already running, open the window of the running program.

Once the program is launched, the main program window is opened (fig.1). It is in this window that you create the list of active machines, select actions that should be done, view the log of either messages from the program itself or operations performed with a machine.




Fig.1 The main program window

The main program window contains:

1. The toolbar with the buttons to perform actions, add, edit or remove machine descriptions and also to select the mode the machine should work in.

The toolbar contains the following buttons:

1. **Add** – allows you to add a new record to the machine list. Once the button is pressed, first you are prompted to enter the machine name, then the window for changing the default machine settings is opened. If you press "OK" in that window, the machine descriptions will be added to the list, otherwise the operation will be cancelled;
2. **Remove** – allows you to remove a machine description from the list. After you remove a description, no operations will be possible for the machine. To do the removing, select the necessary machine from the list and press the "Remove" button;
3. **Setup** – allows you to change the configuration of a previously added machine. To perform this action, you should select the necessary machine and press the button. A dialog window will appear where you can edit the needed parameters. After you press the "OK" button, the changes you have made will be saved.
4. **Receive** – allows you to receive a file from a machine in the manual mode. In this mode the name of the file to be saved is asked and after it is specified, the program switches to the mode for receiving files.
5. **Transmit** – allows you to send a file from the computer to the machine in the manual mode. In this mode the name of the file to be sent is asked and after it is specified, the program switches to the mode for sending files.
6. **Server** – switches the program to the server mode for the selected machine. In this mode files are sent and received automatically without any activity from the user. For the program to work correctly in this mode, you should correctly configure the parameters related to the server mode.

2. The list of machines available for operations. The user creates the list with the help of the buttons on the toolbar.
3. The combo box where all messages either from the program or from the selected machine are displayed
4. The status bar where you can see the status of the program

Warning: it is possible for monitors with low resolution not to display the entire window.

Note: It is the default that the access to the machine parameter settings is granted only after the password is entered. The default password is empty (you can change configuration without password).

4.2 Machine configuration

4.2.1 Port parameters

To configure port parameters, go to the "Port/Port parameters" tab in the options window (fig. 1).




Fig.1 Configuring port and general parameters

Main parameter settings

Serial port – the number of the serial port via which the PC and the NC in the list are connected. .

Polling mode – there are two query modes:

- Event – when the program waits for a signal from Windows that the communications driver has received data and only after that it requests the size of the received data;
- Polling – when the program is constantly querying the communication driver if there are any data inside the internal buffer.

In the first mode the computer resources are saved, but some slow computers can "skip" events and therefore lose data. That is why by default this mode is recommended for fast computers by default. Though if you notice any problems in data transmission, we recommend that you choose the second mode.

The second mode uses relatively more computer resources, but this mode is more stable.

Baud rate – data transmission rate, bits per second. This rate should match that specified on the machine.

Stop bits – the amount of bits added after each transmitted character and indicating the end of the character transmission. The amount of stop bits should match the one selected on the NC.

Data bits – the amount of bits in each character. The amount of stop bits should match the one selected on the NC.

Parity – parity is a mechanism used to track errors while transmitting data. The parity settings should match the settings on the NC:

- None: no error tracking is done.
- Even: One additional bit is sent after each character.
- Odd: One additional bit is sent after each character.
- Mark: the evenness bit is always '1'. Errors cannot be tracked if this type of evenness is selected.
- Space: the evenness bit is always '0'. Errors cannot be tracked if this type of evenness is selected.

RS-485 interface mode – sometimes the communication line between the computer and the NC can be very long, in that case the RS-485 connection standard using a twin-core cable line can be used. In this mode the program will not send data while they are being received, which it is possible according to RS-232.

Clear the buffer when an error occurs while receiving data – when you are just configuring a machine, you may need to see all the data (even if they contain errors) that arrive at the serial port. If it is the case, you should turn this option off. You do not have to do it in the usual working mode. That is why this option is off by default.

4.2.2 Data flow control

To configure port parameters, you should switch to the "Port/Data flow control" tab in the options window (fig.1).




Fig.1 Handshaking setup

Handshaking is used when the NC cannot quickly process the received data. To prevent the input buffer in the NC from being overrun, it tells the program (DNC server) to pause sending data.

The method of exchanging signals between the NC and the DNC server is called handshaking. There are two handshaking methods: software (XOn/XOff) and hardware. For hardware handshaking you will need a special cable for it is performed using special cables in this case.

Software flow control (XOn/XOff) - Two bytes that are not usually used to transmit text are assigned to two special characters of pausing (XOff) and resuming (XOn) data transmission. When the NC wants the DNC to pause sending data, it sends the character XOff (Transmission Off). When the buffer of the NC is empty, it sends the signal XOn (Transmission On), meaning that it is ready to receive data again. The default for XOff is ASCII 19, sometimes also called DC3 (Device Control 3), and ASCII 17 (DC1) for XOn. XOn/XOff are used only for text transmission. They cannot be used to transmit binary data, for binary files may contain the characters XOn and/or XOff.

Hardware flow control (RTS/CTS) - RTS/CTS is a normal form of hardware handshaking. The computer signals via the RTS (Request To Send) line that it wants to send data to the NC, while the NC sends the CTS (Clear To Send) signal when it is ready to receive data.

Hardware flow control (DTR/DSR) - The DTR (Data Terminal Ready) and DSR (Data Set Ready) signals can also be used for handshaking. The DNC server sends the DTR signal when it is ready to send and receive data while the NC uses the DSR signal for that.

It is possible to use both handshaking methods simultaneously. The handshaking settings should match those on the NC.

The characters XOn/XOff - Some machines use nonstandard characters for XOn/XOff, in this case you can specify your own code value for these characters. The character code is specified in the hexadecimal form #XX, where XX is the hexadecimal ASCII character code and can be calculated in the standard Windows calculator. If you are not sure, specify the default values of XOn = #11, and XOff = #13.

Set RTS high - If the RTS signal is not used for hardware handshaking, it can have either low or high level. The default "on" setting is high level.

Set DTR high - If the DTR signal is not used for hardware handshaking, it can have either low or high level. The default "on" setting is high level.

4.2.3 Logging

Logs will help you track and diagnose errors that may occur in the process of configuring and using the program.

To configure the log settings, you should switch to the "Port/Log files" tab in the options window (fig.1).




Fig.1. Log settings

The program has two types of log files:

1. **Received data log files** - these types of files are used to determine the [configuration parameters](#) of the machine when the connection is being established. This file allows you to find out the file format used for transmission and configure the DNC according to it;
2. **Message log files** – when the program is working, there may appear both simple informational and error or warning messages. You can configure the level of details in message logs for each machine. The log file either can never be changed or it can be created each day/hour/month which makes it easier to search for certain information in a log file by date.

For each log file type you can specify folder, where all files will store.

4.2.4 Program format

Each machine (NC) can have its own format of programs that are sent and received. The format of programs can be either common (i.e. its parameters can be applied for programs that are both sent and received) or different for programs that are sent and received.

General settings

To change general settings, you should open the "Format/General" window (fig.1)




Fig.1 General settings

Finish receiving data from the NC after character – if you check this option and specify a hexadecimal character code, the DNC will stop receiving data immediately after it receives this character.

Comment delimiters – these characters separate comments in the program body. In the [server mode](#) comments contain requests to the DNC from the NC, while the DNC in its turn sends [additional information](#) to the NC (such as catalog contents, operation progress status, etc.). It is important to specify those characters correctly, as the correct interpretation of requests and responses depends on this.

Wait Xon before send data - this option allows DNC server transmit data to NC machine only after Xon character receiving, that specified on "[Port](#)" tab, and only if you not use software flow control. This option needs in a some cases, when DNC server can't detect with hardware flow control, that machine is now in the receiving state.

Data exchange

To change these settings, you should open the "Format/Data exchange" window (fig.2).




Fig.2. Data transmission settings

You can configure the data transmission format separately for each direction (sending and receiving). The direction of data transmission is selected from the drop-down list at the top of the dialog window. If the format is the same for both received and sent data you can select the "Same format for receiving and sending" item from the list.

After you select the direction of data transmission, you should first configure the general format of the program. It is characterized by two parameters:

Start – the parameter indicating the beginning of the program. This parameter is a character string and can contain both usual ASCII characters ranging from 32 to 127 or any other character with the code specified in the form of #XX, where XX is the hexadecimal code of the needed character. All the data received prior to this parameter are considered a control header and processed correspondingly. For instance, if you enter the sequence of characters %#0A, the parameter of the program start will be two ASCII characters % and LF.

End – the parameter indicating the ending of the program. All the data received after this parameter are ignored by the DNC and are saved only to the received data log file. The format of this parameter is the same as of the previous one.

Program name prefix – it is by this parameter that the DNC attempts to determine the size of the program file while receiving data.

After you configure the program format, you should configure the format of each program line. This format is also characterized by two parameters:

Start – the parameter telling the DNC that the NC is starting to send a new program line. The parameter is entered in the same format as the previous parameters. If this parameter is not specified, the program starts receiving data from any character. In this case a line is separated only by the line end parameters.

End - the parameter telling the DNC that the NC is finishing to send a program line. The parameter is entered in the same format as the previous parameters. If this parameter is not specified, it will not be possible to separate lines in the general data flow. That is why this parameter is obligatory.

Skip lines starting with – this parameter defines such lines separated by the above-mentioned parameters that are not to be received or sent. If a line has this sequence of characters at the beginning, it will be skipped.

Ignore characters – one or several characters are specified in this input field. When a line separated by the above-mentioned parameters has one of the specified characters, they will be removed from the line.

Skip empty lines when transmitting data – if this option is on and if an empty line (containing only the line start and end parameters) is encountered while transmitting data, it will be skipped.

4.2.5 Characters translation

When you send and receive data, character replacement allows you to get rid of those characters that are unnecessary or unwanted for the DNC server, unacceptable for sending to a machine or incompatible with it. Character replacement is configured separately for each direction of data transmission. (fig.1)




Fig.1 Configuring character replacement

Use the "**Direction**" field to specify the direction to be configured. Once it is specified, you will see what character replacement rules that are already set for this direction in the "**Current translations**" field. To define a rule, you should select the character code in the "**Character**" field and select the rule after that.

- **Keep character** – the selected character will not be changed. This action is default for all characters;
- **Remove character** – the selected character will be removed;
- **Replace with** – the selected character will be replaced with the one specified.

The following additional options are available:

Removing all below ASCII 32 – all characters with a code less than 32 will be removed. It means all unprintable characters.

Removing all above ASCII 127 – all characters with a code greater than 127 will be removed. It means all characters with the code requiring 8 bits of data.

4.2.6 Delays

Some machines need time to process the received data. To save the time for analyzing handshaking signals, you can specify preset delays that will ensure high quality data transmission.

To change time delays, you should open the "Delays" window (fig.1)




Fig.1. Specifying delays

Transfer

Transmission timeout (s) - Use this field to specify the time interval for the DNC to return to the normal working mode.

Delay before transmission start (ms) - Use this field to specify the time for the DNC server to wait before sending data. This time interval will be observed either when a request is received from the NC in the server mode or between files in a cyclic mode of transmitting files.

Delay before each line (ms) - Use this field to specify the time interval to be observed before sending each program line.

Delay between characters in line (ms) - Use this field to specify the time interval to be observed between sending each character in a line.

Handshake resume delay (ms) - Use this field to specify the time interval to be observed between changes of RTS signal from up to down state.

Handshake timeout (s) (Drip feed mode) - our software supports drip feeding the large program to the machine control. In this mode the DNCP sends a portion of data while the machine is receiving it. When the machine can't receive more (a machine memory is full) then the machine sends a signal to a PC (with help of the hardware flow control lines or the XOff character) and the PC waits unlimited time. When the the machine ready to receive a next portion of data then the machine sends Xon or enable hardware flow control and the DNCP send a next portion of data.

Receiving

Receiving timeout (s) - Use this field to specify the time interval for the DNC to return to the normal working mode if no data received at all.

File begin sign timeout (s) - After this interval the DNC will return to the normal working mode if no the program begin sign (usually %) is received. This interval is being measured since any bytes is received from a CNC machine.

File end sign timeout (s) - After this interval the DNC will return to the normal working mode if no the program end sign (usually %) is received. This interval is being measured since the program begin sign is received.

Handshake resume delay (ms) - Use this field to specify the time interval to be observed between changes of RTS signal from up to down state.

4.2.7 Manual mode

Configuration

The manual mode is used to send and receive files under the control of the PC user. Depending on the granted permissions, the user can load files either from the specified folder or from any folder on the disk. The same is true for receiving files.

The behavior of the user and the program is determined by the settings specified on the "Manual mode/Directories and files" tab (fig.1).




Fig.1 Manual mode. Configuration.

- **Folder for files to be sent to the machine**
- **Folder for files received from the machine** – these two folders define the location on the disk to be used by default for loading and unloading files. If you check the "Do not allow users to save/load files to/from other folders" option, the user will be able to choose files only from the folder specified in this field.
- **Do not allow users to save files to other folders**
- **Do not allow users to load files from other folders** – this option restricts the user in choosing the location of files and prevents casual loss of information resulting from mistakes in his actions. If this option is on, files are always found in the specified location.

While transmitting files from the machine to the computer, sometimes it happens so that the transmitted file already exists on the disk in the specified folder. In this case the program will follow the instructions specified in the "Backup" group.

Mode – defines what the program should do if it turns out that such a files already exists on the disk

- **Disabled** – no backup copies are created. The old file is replaced by the new one
- **Copy old files to the backup folder** – the file that already exists in the folder specified for saving will be moved to another folder (specified below)

- **Rename the old file** – the file existing in the folder will not be moved, but only renamed. An identification number 1, 2, 3 etc. will be added to its name.
- **Rename the new file** – the files existing in the folder will remain unchanged, while the new file will be renamed. Renaming is done as described above.

If mode #2 is selected, the "**Folder**" input field becomes available for editing. Here you can specify the location on the disk where backup copies of files will be placed.

Autocreate directories – is this option is on, all the folders specified above will be created automatically. It means that you will not have to create them before launching the program. If the folder already exists, it will remain unchanged.

Transmitting files from the machine to the computer

You should do the following to transmit a file in this mode:

1. Select a machine from the list in the main program window;
2. Press the "Receive" button;
3. Specify or choose the filename and the path. If the file exists, you will be asked the question "Replace the file?". If you are sure, press "Yes".
4. Press "OK".

After this the program will switch to the mode for receiving files. After that you should press the PUNCH button on the machine itself. If the machine was configured correctly, the message log will reflect the process of receiving the file. The final message will be that the file is successfully received. In any other case an error message will be displayed.

If for any reason you decide to cancel receiving the file, press the "Stop" button on the toolbar in the main program window.

Transmitting files from the computer to the machine

You should do the following to transmit a file in this mode:

1. Select a machine from the list in the main program window;
2. Press the "Send" button;
3. Specify or choose the filename and the path.
4. Press "OK".

After this the program will switch to the mode for sending files and will wait until the receiving device is ready. After that you should press the READ button on the machine itself. If the machine was configured correctly, the message log will reflect the process of sending the file. The final message will be that the file is successfully sent. In any other case an error message will be displayed.

If for any reason you decide to cancel sending the file, press the "Stop" button on the toolbar in the main program window.

4.2.8 Variables

Dates

`$DATE$` - The date in the format set on the computer. Example: 29/04/04

`$TIME$` - The time in the format set on the computer. Example: 13:12:02

`$DATETIME$` - The date and time in the format set on the computer. Example: 29/04/04 13:12:02

`$DATESTRIP$` - The date in the format set on the computer, but only digits. Example: 290404

`$TIMESTRIP$` - The time in the format set on the computer, but only digits. Example: 131202

`$DATETIMESTRIP$` - The date and time in the format set on the computer, but only digits. Example: 290404 131202

`$DATECLEAN$` - The date in the format set on the computer, but only characters that can be used in a filename. Example: 29-04-04

`$TIMECLEAN$` - The time in the format set on the computer, but only characters that can be used in a filename. Example: 13-12-02

`$DATETIMECLEAN$` - The date and time in the format set on the computer, but only characters that can be used in a filename. Example: 29-04-04 13-12-02

`$DATEA$` - the abbreviation for the current day of the week

`$DATEAA$` - the full name of the current day of the week

`$DATEB$` - the abbreviation for the current month

`$DATEBB$` - the full name for the current month

`$DATED$` - the number of the current day (01\$ - 31).

`$DATEJ$` - the number of the current day in the year (001\$ - 366).

`$DATEM$` - the number of the current month (01\$ - 12).

`$DATEU$` - the number of the current week in the year, where Sunday is the first day of the week (00\$ - 53).

`$DATEW$` - the number of the current day of the week, (0\$ - 6; Sunday = 0).

`$DATEWW$` - the number of the current week in the year according to the ISO standard, where Monday is the first day of the week (00\$ - 53).

`$DATEY$` - the current year, the last two digits as a number (00\$ - 99).

`$DATEYY$` - the current year in full.

\$TIMEH\$ - The current hour in the 24-hour (ISO) format (00\$ - 23).

\$TIMEI\$ - The current hour in the 12-hour format (01\$ - 12).

\$TIMEM\$ - The current minute (00\$ - 59).

\$TIMEP\$ - the pm/am indicator for the 12-hour format

\$TIMES\$ - the current second (00\$ - 59).

Program name

\$RECVONO\$ - the number of the received program with a prefix. Example: O12

\$RECVONO4\$ - the 4-digit number of the received program with a prefix. Example: O0012

\$RECVONO6\$ - the 6-digit number of the received program with a prefix. Example: O000012

\$RECVONO8\$ - the 8-digit number of the received program with a prefix. Example: O00000012

Path

\$ORGPATH\$ - the filename sent or received last and its path. Example: C:\MILL\Mould.nc

\$ORGNAME\$ - the filename sent or received last. Example:: Mould.nc

\$ORGNAMENOEXT\$ - the filename sent or received last without its extension. Example:: Mould

\$ORGEEXT\$ - the extension of the file name sent or received last. Example:: nc

\$ORGDIR\$ - the path of the file that was sent or received last. Example:: C:\MILL

Machine

\$PORTNAME\$ - the name of the serial port. Example: COM1

\$MACHINENAME\$ - the name of the machine in the configuration. Example: Generic CNC Machine

\$MACHINEDESC\$ - the description of the machine in the configuration. Example: Left-top corner of the hall 1

\$OPERATOR\$ - the machine operator login received from the machine using the "Operator name" command.

Report variables

\$RECVPRGNAME\$ - the name (number) of the program received last. Example: 5643

\$RECVFILESIZE\$ - the size in bytes of the program file received last. Example: 604

\$RECVFILENAME\$ - the full name of the program file on the disk received last. Example: TEST.NC

\$RECVDIRNAME\$ - the name of the folder where the program file received last was saved. Example: C:\MILL\

\$RECVPATH\$ - the full name of the program file received last and its path. Example: C:\MILL\TEST.NC

\$RECVERRTEXT\$ - a brief description in the English language of the error that occurred while receiving the last file. Example: File not found.

\$RECVBYTES\$ - the amount of the received bytes

\$RECVLINES\$ - the amount of the received lines

\$RECVERRORS\$ - the amount or errors that occurred during the process of receiving

\$RECVLPS\$ - data receiving rate (lines per second)

\$RECVCPSS\$ - data receiving rate (characters per second)

4.2.9 Server mode

4.2.9.1 Settings

{Available only in the full professional version}

It is the most "advanced" and intellectual working mode of the program. In this mode all the program actions are performed automatically without the PC user actions. When the program is launched, it is automatically switched to the mode for receiving information from the machine. When receiving some data, the program analyzes their contents and depending on the processed information performs responds in one way or another:

- transmits a program file to the machine;
- receives a program file from the machine;
- transmits the information about files located in the specified or requested folder;
- deletes files in the specified folder;
- renames files located in the specified folder.

Folders for receiving and sending files are specified in the same way as in the previous section – "[Manual mode](#)".

Commands from the machine to the computer can be transmitted in two ways:

- **As commands in the control header of the transmitted data block** - the set of these commands is limited and directly depends on the machine manufacturer. Some machines may have no such commands. Often the control header is present in the machines with the feature of loading the programs from an external disk drive, working via the RS232 interface.
- **As commands transmitted in the program body** - is the most convenient way of transmitting the information between the machine and the PC. Nearly any information can be transmitted in this form. In this case the data transmission format is determined by the message protocol, accepted on the DNC server. Using this way, the NC operator can request the information (folder

contents, files) from the DNC server. The NC operator sends a small program to the DNC with the requests, to which he would like to receive responses.

Header commands

The commands are extracted from the header according to the parameters specified in the "Server mode/NC commands format" tab (fig.1)




Fig.1 NC command format

If you are sure, that your machine uses service commands in the header (for example, you have found it out analyzing the log file), first it is necessary to enable this mode in the "**Processing commands from NC**" field. After that it is necessary to specify the parameters by which the commands will be extracted from the general information flow.

Basic settings

Start – the parameter indicating the beginning of a command. This parameter is a character string and it can contain usual ASCII characters ranging from 32 to 127 as well as any other character with the code specified as #XX, where XX is the hexadecimal code of the necessary character. All data received prior to this attribute are not considered as commands and are ignored. For example, if you

enter the #1B#26 character sequence, two ASCII characters – ESC (ASCII 27) and & – will be considered as the command start parameter.

End – the parameter indicating the end of a command. This parameter is a character string and it can contain usual ASCII characters ranging from 32 to 127. The parameter input format can be specified in the same way as the previous one. All data received after to this parameter are not considered as commands and are ignored.

The first N characters are the command name – after a command is separated from the program header or body using the parameters specified above, it is also necessary to identify its name and possible value. To do it, specify how many of the first characters are the name of the program. In addition to it, you can specify (**only letters**) that the name of the program can contain only letters. Thus, the maximum size of the command name is limited, but if the last characters are not letters, they will be cut off from the command name and added to the beginning of the command body.

Command name and name body are separated by - this field allows you to specify a separator between command name (H,FW, etc) and command body (file name, message etc).

Advanced settings

These settings allow to open all command extraction features, but require additional knowledge in [regular expressions](#).

Use regular expressions – to separate commands from the service header or from the program body, we will use perl-like regular expressions widely used to process text data. Having specified one or more regular expressions (each regular expression is specified on a separate line), you will define the corresponding amount of rules for processing incoming data. When specifying a regular expression, you should have two matches as the result of its work. The DNC server will consider the first match to be the name of the command, while the second match will be considered the body of the command.

Commands in the program body

The DNC server can process commands transmitted in the program body. For a command to be correctly identified, the following conditions should be observed:

1. All commands sent to DNC must be transmitted in the NC program that has the name specified in the "**Search for requests only in the program named**" field (fig.1);
2. The name of the NC program must be transmitted in its first line and it must be of the format specified in the section. If everything is observed, DNC identifies the program name as the command in the program body that can be separated from the program body using the corresponding regular expression.

An example of the program for the NC operator to type:

```
O8888
N0010 (DIR=/VIPROS)
N0020 (PRG=0010)
%
```

The first line specifies the program name. In the DNC settings for the current machine this name should match the one specified in the "**Search for requests only in the program named**" field, because DNC will search for requests from the NC only in programs with this name.

The second line contains the DIR =/VIPROS command that defines the folder for the operation of receiving a file or folder contents to be performed in.

The third line contains the PRG=0010 command telling the DNC server to send the file named 0010 to the machine. To obtain the actual name of the file, the DNC server generates it from the prefix (it will be added before 0010), the suffix (will be added after 0010) and the extension (will be added at the end and separated from the suffix with a dot). After that it will search for the file in the specified folder.

The last line with the % character indicates the end of the program and it must match the one specified in "[Program format](#)".

After the NC operator sends a request, he should switch to the mode for receiving data from the DNC server within 3 minutes. If he does not do it, the DNC server will switch back to the mode for expecting requests from DNC. The request will result in either a file, or the disk contents, or the status of performing the operation.

Command triggers

If all the above-mentioned conditions are observed, the process will result in identifying one or several commands that the DNC server will be able to execute. Now it is necessary to match the identified command names with those supported by the DNC server. It is done in the " NC command names" list. The DNC server supports and can execute the following commands:

- **Send a file** – once the DNC server receives this command, it will queue the file the name of which was transmitted in the command body for sending. The final filename is generated from the prefix, the suffix and the extension specified on the "Folders and files" tab (fig.2).
- **File list** – once the DNC server receives this command, it will queue the contents of the folder (or folders) specified on the "Directories and files" tab (fig.2) in the "**Folder for files to be sent to the machine**" list for sending.
- **Set the relative path** – the name of the folder where the DNC server should search for programs to be sent to the machine. The folder name is defined relative to the folders specified on the "Directories and files" tab. For example, suppose C:\NC is specified in the DNC settings for the current machine and the body of the received command is VIPROS, in this case the server will search for files in the C:\NC\VIPROS\ folder. If this command is not specified, the search for files is performed only in the folder specified in the DNC settings for the current machine.
- **Skip** – if you specify this action for a command, the command with this name will be skipped and there will be a record added to the message log informing that this command has been ignored.
- **Set the file for operations** – when this command is executed, the filename transmitted in the program body will be remembered and used for further operations (for example, renaming). If this command is the last one in the list of the processed commands, it will mean the request for sending the file with this name.
- **The name of the received file** - this command tells the DNC server that the command body is the name of the program that is being sent to the DNC server at the moment. Depending on this name, the server searches for commands in the program body because the name of the

program to search for commands in is specified in the options (fig.1). In case of non-service programs, this filename is used for saving the program file to the disk.

- **Delete the file** – the file the name of which is specified in the command body is deleted. The file is removed from the first found folder specified in the "**Folder for files to be sent to the machine**" list in the options.
- **Rename to** – the file the name of which was set earlier by the "**Set the file for operations**" command will be renamed to the file specified in the command body. Renaming is done in the first found folder specified in the "**Folder for files to be sent to the machine**" list in the options.
- **Cancel current operation in the queue** – this command instructs the DNC Precision to immediately cancel current command. This command is used if you want to cancel a current drip-feed operation and request a new file.
- **Cancel all operations in the queue** – this command instructs the DNC Precision to immediately cancel current command and clear all commands in the queue. This command is used if you want to cancel a drip-feed operation and request a new file, but you queue some files to send before.
- **Operator name** - this command sets the operator name. The operator name is used in the [machine monitor](#) later. If you are using the machine monitor function you can instruct your operators to use this command when the operator starts their job.
- **Tool break** - this command requests a file partially when a tool is broken and you stopped your machine. The command is described in the following [section](#).
- **Tool break add before, Tool break add after** - these commands are used in conjunction the tool break command. This commands are described in the following [section](#).




Fig.2 Directories and files

You may define multiple folders with subfolders to search a program requested. DNC Precision will send first found file that match your file name prefix, suffix and extension (see fig.2). If your folders contains files with different extension you may define all your extensions in the "Extension" field. In this case all extensions are semicolon delimited. For example, if your folders contain files like *.nc, *.ncp, *.iso, then you may define the extension string like "nc;ncp;iso" (w/o quotes). In this case the program will use all these extension for search.

4.2.9.2 File list

{Available only in the full professional version}

In the server mode the DNC server can process the request to send the list of files located in the folder specified in the "Folder for files to be sent to the machine" field on the "Server mode/Directories and files" tab.

After receiving the request to transmit the file list described in the "[Commands in program body](#)" section, the DNC server will generate the file list in a pseudo-program form with the format specified by the user on the "Server mode/File list" tab (fig.1). Then the generated pseudo-program is ready to be sent to the machine. The NC Operator, in his/her turn, should switch the NC to the data receiving mode. Once it is done, the NC operator receives the program with the file list in its body.




Fig.1 File list format

Example: If the operator sends:

```
O8889
N0010 (PRG=DIRLIST)
%
```

The DNC server will respond:

```
:8889 feed
N1000 ( DIRECTORYLIST FOR COM2 )
N1010 ( -----)
N1020 (1111 28.01.2004 12:23:30 121)
N1030 (8888 28.01.2004 13:07:00 23)
N9999 ( END OF LISTING )
M30
%
```

Allow file list request – this option allows the DNC server to process the requests to send the file list. If this option is off, the request to read the file list will be ignored, with the [report](#) generation option on, the NC operator will be sent an error message.

List request identifier – requests to send the file list can be transmitted not only in the request program body as it is described in the "[Commands in the program body](#)" section, but also as a separate, empty request program having its own name. This program name (specified in its first line) is the identifier. Having received the program with such an identifier, the DNC server generates the file list and sends it at once.

Insert at the beginning of the list, Insert at the end of the list - allows you to create the file list header and its ending to your liking. Between the list header and its ending the generated file list will be inserted. Specifying these fields you can use the \$PORTNAME\$ variables, describing the current DNC server status. The full description of the variables can be found in the "[Variables](#)" section.

Note: When sending the data from these fields the program will try to determine the syntax of the entered data. It means that the line numbers and comment characters will **NOT** be added to the following lines:

- without the % character at the beginning;
- not beginning with the prefix set for the program name in the "[Format](#)" section;
- beginning with the sequence of the G50 kind, which is a standard G-code.

Column 1..3 - these combo boxes specify the format in which one line in the file list describing one file from the folder should be displayed. The following values are possible:

- No - do not display anything in this column;
- File name without extension - only the file name will be displayed in the column. Example: TESTFILE
- File name – the file name and its extension will be displayed in the column. Example: TESTFILE.NC
- Path - the file path will be displayed in the column. Example: C:\NCPROGRAMS
- Name and path - the file path and its full name will be displayed in the column. Example: C:\NCPROGRAMS\TESTFILE.NC
- File size - the file size in bytes will be displayed in the column. Example: 680
- File date - the file creation date will be displayed in the column. Example: 12/12/2004
- File time - the file creation time will be displayed in the column. Example: 12:12:04
- File date and time - the file creation date and time will be displayed in the column. Example: 12/12/2004 12:12:04

Send in comments - if this option is on, the file list will be included in the comment delimiters specified in the program [format](#).

Number lines when sending - if this option is on, each line of the file list will be numbered. Line numbering will start at 1000 with the step of 10.

Note: If you enable the "**Number lines when sending**" and "**Send in comments**" options, but you want some of the lines to be transmitted unchanged (without numbers and comments), put the '!' character at the beginning of the line (see the example below).

Template text example:

```
!:8889 feed
DIRECTORYLIST FOR $PORTNAME$
-----
```

or

END LISTING
!M30

4.2.9.3 Reports

{Available only in the full professional version}

While transmitting and receiving files, processing requests in the automatic mode, it is sometimes necessary to inform the operator about the operation performance status. It can be done with the help of reports. The DNC server can generate the following types of reports:

- the file has been successfully received from the NC;
- the file has not been successfully received from the NC;
- the request has not been completed.

To edit report parameters, you should switch to the "Server mode/Reports" tab (fig.1).




Fig.1. Reports parameters editing.

Report type – selecting the report type which parameters you want to edit

Enable report - if you enable this option the current report will be generated and sent to the machine

Send in comments – the lines of the report generated from the template will be included between the comments

Number lines when sending - lines of the report generated from the template will be numbered starting at 1000 with the step of 10

Report text – the report text template you want to send. You can use variables in the report text. Generating the reports the additional variable set for the reports can be used.

Note: If you enable the "**Number lines when sending**" and "**Send in comments**" options, but you want some of the lines to be transmitted unchanged (without numbers and comments), put the '!' character at the beginning of the line (see the example below).

Template text example:

```
! :9997
SUCCESS!
TIME $TIMESTRIP$
DATE $DATESTRIP$
-----
RECEIVED PROGRAM $RECVPRGNAME$
SIZE $RECVFILESIZE$
FILENAME $RECVFILENAME$
DIRECTORY $RECVDIRNAME$
-----
!M30
```

4.2.9.4 Tool break command

{Available only in the full enterprise version}

This is the command used to identify the file that you wish to partially download. This configuration page allows you to define the header, body, and trailer sections of the program. These sections will then be assembled into a temporary file and send to a machine, so that you can re-execute the portion of the program that occurred after the tool break. The operator should send to DNC Precision a control program like:

```
%
08888
(TOOLBREAK=N100)
(PRG=0010)
%
```

This program contains the following commands:

TOOLBREAK=N100 - specifies the tool break line in the program and contains two parts:

1. TOOLBREAK. It is the command name. This command name should be defined in [the NC commands trigger list](#) and assigned to the "Tool break" action. You may use any word instead of TOOLBREAK. In this case you should make corresponding changes in the control program above and in [the NC commands trigger list](#).
2. N100. It is the tool break line. You may define here:
 - If your program contains numbering - program line number, like "N100";
 - If you program doesn't contain numbering - any text that appears in the program, like "X0.001Z100". DNC Precision will search first line with this text and use this line as a tool break line.
 - You may specify any number, like "100". DNC Precision will use the line with this number as a tool break line.

PRG=0010 - specifies the program name to send. This command queues the program with this name to send. This file will be preprocessed to a temporary file before sending. DNC Precision will use header and footer sections and rules in these sections to assemble a temporary file.




Fig.1. Tool break command.

Tool break header (Inserting at the beginning of the file)

This optional strings contain may contain any text and special variables (enclosed by \$\$) that will be added to a temporary file. Text lines will be added without modifications. All variables will be replaced with corresponding values.

Tool break variables

PROGNAME - the program name. DNC Precision searches the program body for first entry of the "[Program name prefix](#)" and use these characters as a program name.

FIRST - DNC Precision searches for first entry of specified text. Example:

FIRST:G#0+X+Y+Z:ROWSABOVE. The variable contains three parts:

1. **FIRST** - variable name;
2. **G#0+X+Y+Z** - the search condition. You may define any text here (except \$ character) or define a complex search condition. The complex search condition means that a target line should match all or one of rules defined in this complex search condition. The complex search condition may contain "AND" or "OR" conditions. The "AND" condition example is "**G01+X+Y+Z**". This complex condition instructs DNC Precision to search a line that contains G01 and X and Y and Z strings. The "OR" condition example is "M03|M04". This complex condition instructs DNC Precision to search a line that contains any from M03 or M04. You may use both AND and OR conditions at same time. The following example illustrates this condition "**G01+X+Y|Z**". The AND condition has more priority than the OR condition. Therefore the DNC Precision will search a line that contains G01 and X and one of Y or Z. The search text may contain a special character #, like G#0. This character instructs DNC Precision to search any text that may contain one or more "0" (zero) at this position. Therefore the G#0 condition may match G0, G00, G000, etc. M#3 condition may match M3, M03, M003, etc.
3. **ROWSABOVE** - optional one or more variable parameters. These parameter are delimited by comma.

RECENT - DNC Precision searches for most recent entry of specified text from the tool break line (except the tool break line). It means that DNC Precision search text backward, from the tool break line to the top of the file. Example: *RECENT:X*. The format of this variable is same of the "FIRST" variable.

OPERATORDATA1, OPERATORDATA2 - this variable will be replaced with a text that send an operator in the control program.

Variable parameters

Note: These parameters are applicable for FIRST and RECENT variables only.

ROWSABOVE - DNC Precision copies all lines above the found line to a temporary file;

ROW - DNC Precision copies the found line to a temporary file;

ROWS### - DNC Precision copies ### lines (where ### is any positive number) after the found line to a temporary file;

SEEK - DNC Precision uses this line as a temporary tool break line for next FIRST or RECENT variable;

CS - the search is sensitive to a characters case. If this parameter isn't defined, then the search is case insensitive;

RE - the search string is a regular expression (advanced usage).

Options

Allow operator to add beginning rows - if this options is enabled then **OPERATORDATA1** may be replaced with a text that operator may specify in the control program. Otherwise this variable will be replace with empty line.

Allow operator to add ending rows - if this options is enabled then **OPERATORDATA1** may be replaced with a text that operator may specify in the control program. Otherwise this variable will be replace with empty line.

Renumber all rows - if this options is enabled then DNC Precision will renumber all rows before sending the temporary file. Otherwise you may define line numbers in the header and footer templates.

Real world example

The control program:

```
%
O8888
(PRG=100)
(TOOLBREAK=N000299) <-- Tool break line
%
```

The header template:

```
%
$PROGNAME$
(TOOL BREAK)
(-----)
$FIRST:G#0+X+Y+Z:ROWSABOVE$
$FIRST:G#0+X+Y+Z:ROW$
$RECENT:M#3|M#4$
$RECENT:X$ $RECENT:Y$
G01$FIRST:G#0+Z$$RECENT:F$
$RECENT:Z$
$OPERATORDATA1$
```

The footer template:

```
$OPERATORDATA2$
(-----)
%
```

The source program:

```
%
O0100
N000001 G90 G80 G00 G17 G40 G54
N000002 G43 H1 Z80. S3000 M03
N000003 G00 X94.11 Y0.0 Z60. M08
N000004 Z15.
N000005 G01 Z10.8 F840
N000006 X111.61 F2800
N000007 X174.11
N000008 Y-7.025
```

N000009 X196.941
N000010 G02 X226.615 Y-2.599 I25.5 J-69.276
N000011 G01 X238.56
N000012 Y2.599
N000013 X226.491
N000014 G02 X197.014 Y7.024 I-3.984 J73.849
N000015 G01 X174.11 Y7.023
N000016 Y0.0
N000017 X161.61
N000018 Y-19.525
N000019 X199.276
N000020 G02 X226.245 Y-15.099 I23.166 J-56.776
N000021 G01 X251.06
N000022 Y15.099
N000023 X226.139
N000024 G02 X199.343 Y19.524 I-3.631 J61.349
.....
N000205 Z12.6
N000206 G01 Z8.4 F840
N000207 X111.61 F2800
N000208 X194.836
N000209 X174.11
N000210 Y-0.339
N000211 X215.562
N000212 X218.886 Y-0.105
N000213 X224.072 Y-0.133
N000214 X238.56
N000215 Y0.134
N000216 X224.401
N000217 X218.883 Y0.105
N000218 X215.562 Y0.339
N000219 X194.836
N000220 Y12.839
N000221 X161.61
N000222 Y-12.839
N000223 X216.002
N000224 X219.291 Y-12.607
N000225 X224.072 Y-12.633
N000226 X251.06
N000227 Y12.633
N000228 X224.335 Y12.634
N000229 X219.289 Y12.607
N000230 X216.002 Y12.839
N000231 X194.836
N000232 Y25.339
N000233 X149.11
N000234 Y-25.339
N000235 X216.442
N000236 X219.697 Y-25.11
N000237 X224.072 Y-25.133
N000238 X263.56
N000239 Y25.133
N000240 X224.27 Y25.134
N000241 X219.696 Y25.11
N000242 X216.442 Y25.339
N000243 X194.836

N000244 Y37.839
N000245 X136.61
N000246 Y-37.839
N000247 X216.881
N000248 X220.103 Y-37.612
N000249 X224.072 Y-37.633
N000250 X275.349
N000251 X276.06 Y-36.943
N000252 Y36.824
N000253 G02 X275.261 Y37.633 I29.106 J29.569
N000254 G01 X224.204 Y37.634
N000255 X220.103 Y37.612
N000256 X216.881 Y37.839
N000257 X194.836
N000258 Y50.339
N000259 X125.412
N000260 X124.11 Y49.841
N000261 Y-49.848
N000262 X125.399 Y-50.339
N000263 X217.321
N000264 X220.51 Y-50.114
N000265 X224.072 Y-50.133
N000266 X281.298
N000267 X281.83 Y-49.329
N000268 X284.328 Y-46.338
N000269 X286.495 Y-44.235
N000270 X288.56 Y-42.606
N000271 Y42.63
N000272 G02 X281.165 Y50.133 I16.606 J23.764
N000273 G01 X224.138
N000274 X220.51 Y50.114
N000275 X217.321 Y50.339
N000276 X194.836
N000277 X199.836 Y57.839
N000278 G03 X194.836 Y62.839 I-5. J0.0
N000279 G01 X123.082
N000280 X119.926 Y61.62
N000281 X117.146 Y60.612
N000282 X116.77 Y60.532
N000283 X112.002 Y60.27
N000284 X111.951 Y59.889
N000285 X111.673 Y56.807
N000286 X111.61 Y53.651
N000287 Y-53.651
N000288 X111.672 Y-56.807
N000289 X111.95 Y-59.888
N000290 X112.001 Y-60.261
N000291 X116.77 Y-60.566
N000292 X117.215 Y-60.667
N000293 X119.926 Y-61.627
N000294 X123.082 Y-62.839
N000295 X217.76
N000296 X220.916 Y-62.617
N000297 X224.072 Y-62.633
N000298 X288.016
N000299 X291.871 Y-56.807

```
N000300 X293.503 Y-54.852
N000301 X294.741 Y-53.651
N000302 X296.036 Y-52.629
N000303 X296.659 Y-52.25
N000304 X301.06 Y-50.783
N000305 Y50.792
```

```
.....
```

```
M30
```

```
%
```

The result program:

```
%
O0100                                     <--- PROGNAME variable
N00010 (TOOL BREAK)                       <--- copied by $FIRST:G#0+X+Y+Z:ROWSABOVE$
N00020 (-----)                          <--- $FIRST:G#0+X+Y+Z:ROWSABOVE$
N00030 G90 G80 G00 G17 G40 G54            <--- $FIRST:G#0+X+Y+Z:ROWSABOVE$
N00040 G43 H1 Z80. S3000 M03              <--- $FIRST:G#0+X+Y+Z:ROWSABOVE$
N00050 G00 X94.11 Y0.0 Z60. M08           <--- $FIRST:G#0+X+Y+Z:ROW$
N00060 M03                                <--- $RECENT:M#3 | M#4$
N00070 X288.016 Y-62.633                  <--- $RECENT:X$ $RECENT:Y$
N00080 G01Z60.F2800                       <--- G01$FIRST:G#0+Z$$RECENT:F$
N00090 Z8.4                               <--- $RECENT:Z$
N000299 X291.871 Y-56.807
N000300 X293.503 Y-54.852
N000301 X294.741 Y-53.651
N000302 X296.036 Y-52.629
N000303 X296.659 Y-52.25
N000304 X301.06 Y-50.783
N000305 Y50.792
.....
M30
%
```

4.2.10 Machine monitor

4.2.10.1 Settings

{Available only in the full enterprise version}

The DNC Precision Machine monitor function utilises the Fanuc Macro-B functions to passively monitor Cycle start, Cycle stop, Tool change and other events that your machine can generate. The following describes how to set it up.

If you have "User Macro B" in your Fanuc control, you can use the POPEN, DPRNT, and PCLOS statements. Not all Fanucs have this option, however, so we use another method as well. On any Fanuc control, if you go to EDIT mode and type: POPEN then press INSERT, the CNCs that have the option will display the word just like it's shown. If it puts spaces between each letter, like this:

```
P O P E N
```

then the CNC doesn't recognize the POPEN key word, and you don't have the option.

Insert a Macro Call Command at the beginning of the NC Program, right after the 'Onumber', and another Macro Call Command at the end, just before 'M30'. These quite simple macros utilise the DPRNT declaration to transmit a short character string from the serial port of the CNC. At the beginning of all NC programs, insert this Macro Call:

```
O9010 (CYCLE START MACRO)
POPEN
DPRNT[ (**CYCLESTART**) ]
PCLOS
M99
```

```
O9010 (CYCLE STOP MACRO)
POPEN
DPRNT[ (**CYCLESTOP**) ]
PCLOS
M99
```

If you use certain O-numbers for these macros, you can also assign a custom G-code or a custom M-code to automatically call them. In some cases, you won't even need to modify your programs at all. For example, if all your programs have a certain G-code at the beginning (say, "G20" for Inch programming), you can just put the number "20" in a parameter to make "G20" always call macro 9010. In a similar fashion, you can have the control call the "CYCLESTOP" macro with the M30. The parameter locations for these settings are different in each model Fanuc control, so you will have to look them up in the manual.

On the DNC side, just keep the port open and listen for the word "CYCLESTART" or "CYCLESTOP" (followed by a Line-Feed) then record the event in a file with the Date and Time variables from the PC's internal clock. You can then go back later and analyze all these events and calculate how many cycles you have, average cycle time, average load time, etc. We even tie this into our automatic paging and e-mail software so someone can get a page or e-mail if the machine has been idle for more than (x) minutes.

For machines that DON'T have User Macro B, you can try another method for cycle start/stop monitoring:

You can use a small relay and connect it to the signal that powers the "in cycle" light bulb or LED on the operator's panel. This relay then turns on one of the unused handshake lines on the RS232 cable (say, pin #8, or CD). Our DNC software just watches this signal, and knows the CNC is in cycle if it's on, and out of cycle when it's off. In this case you can't use activity triggers and can use cycle start/stop monitoring only. You can enable this feature on the ["Additional options"](#) tab.




Fig.1 NC activity triggers

Basic and advanced settings are very familiar with same settings of the [server mode](#). Here, you can define rules, that our software will use to extract your activities. Please, note that you should use another format of activities if you are using the server mode, because your activity trigger names can interfere with NC commands in the server mode.

Default values are:

Activity start: (***)

Activity end: (***)

So your activity will be (**A=1234**) or a program with activity within:

```
O9010 (CYCLE STOP MACRO)
POPEN
DPRNT[ (**A=1234**) ]
PCLOS
M99
```

It is an example only and you can define your own rules and activity triggers. You can use many build-in trigger names and their interpretations or define new one. For example you can define a trigger with name "A" and interpretation "Smoking" and the program will export this text to a log file.

So you defined activity triggers. If you didn't define a trigger name, then the trigger with this name will not be exported.

The list of activity triggers is not limited by cycle start/stop commands. You can define few macro or call DPRINT within your main program. Some examples are listed below:

When a spindle start command (M03 or M04) is executed, this macro is called:

```
O9xxxx
POPEN
DPRNT[ TOOLCHANGE=#4120[ 40 ] ]
PCLOS
M99
```

The DNC software will write this activity and tool number to a log file.

When a spindle stop command (M05) is executed, this macro is called:

```
O9xxxx
POPEN
DPRNT[ TEXTMSG=Punch beginning ]
PCLOS
M99
```

The DNC software will write your custom message to a log file.

4.2.10.2 Additional options

{Available only in the full enterprise version}

This page will be activated if you'll enable the "Log activity" box on the previous page.




Fig.1 Additional options

Export "Start/Stop sending" event – the program will write a text message to a log file when the program start and stop sending a program to a machine in the server mode. It can help you to track a operator activity.

Export "Start/Stop receiving" event – the program will write a text message to a log file when the program start and stop receiving a program to a machine in the server mode. It can help you to track a operator activity.

Monitor status of pin #8 (CD) - You can use a small relay and connect it to the signal that powers the "in cycle" light bulb or LED on the operator's panel. This relay then turns on one of the unused handshake lines on the RS232 cable (say, pin #8, or CD). Our DNC software just watches this signal, and knows the CNC is in cycle if it's on, and out of cycle when it's off and write a corresponding row to a log file.

- **Debounce intervals** – this intervals can help you to remove non-significant events that can generate a relay. 0 - don't use a debounce interval.
- **Invert CD signal** - it depends on your relay connection schematic.
- **Ignore CD signal while sending data** - some machine turn "In cycle" signal off when receiving data over RS232 interface. In this case this option can help you exclude non-significant events.

4.2.10.3 Export monitor data

{Available only in the full enterprise version}

This page will be activated if you'll enable the "Log activity" box on the "Settings" page.

Our software can export monitor data to many targets with help of [data export plugins](#). All targets are listed in the "Export targets" list. You can [download](#) data export plugin for your needs from our site and install it. Most plugins are free for registered customers. Before exporting data you should assign a data for each column in a target document (Excel, database table, etc). You can do it with help of the "Columns" table. Simply, select a data description from a drop-down list.

When you assigned columns, then you can activate a data target in the list and configure this target by clicking the "Setup" button. The plugin's setup options are described in the help file that is bundled with a corresponding plugin module and you can open this file by clicking the "Help" button.




Fig.1 Export monitor data

This real world example describes a machine that has a probe to measure components after they have been machined.

The machine has a 25 pin RS232 port which we have connected to a laptop using a 9 pin RS232, and have been able to receive data.

You will need DNC Precision with machine monitor function enabled. The input/output port setting on the SETTINGS page of OFFSETS key will need to be set to 0 (zero) to point output to the RS232.

Type and start the demo program below. Don't forget POPEN and PCLOS top AND BOTTOM.

```
%  
O1919(DPRINT TEST)  
#4=4444.  
#5=5555.  
#18=18.18  
#1=111.1  
#25=25.25  
#28=28.28  
#29=29.29  
#137=137.137  
#138=138.138  
#139=139.139  
#143=143.143  
POPEN  
DPRNT[ (**COMPONENT=#121[60]**)]  
DPRNT[ (**FEATURE=#122[40]**)]  
DPRNT[ (**PCDFEATURE=#147[30]**)]  
DPRNT[ (**INCX=#4[44]**)]  
DPRNT[ (**ACTUALX=#28[44]**)]  
DPRNT[ (**INCY=#5[44]**)]  
DPRNT[ (**ACTUALY=#29[44]**)]  
DPRNT[ (**PCD=#18[44]**)]  
DPRNT[ (**ACTUALPCD=#137[44]**)]  
DPRNT[ (**DEVPCD=#142[34]**)]  
DPRNT[ (**ANG=#1[44]**)]  
DPRNT[ (**ACTUALANG=#139[44]**)]  
DPRNT[ (**DEVANG=#144[34]**)]  
DPRNT[ (**SIZEY=#25[44]**)]  
DPRNT[ (**ACTUALSIZE=#138[44]**)]  
DPRNT[ (**TOL=#11[24]**)]  
DPRNT[ (**DEVSIZE=#143[34]**)]  
PCLOS  
M30  
%
```



4.3 Windows 2000+ service

Windows 2000+ services use will let you:

- control service on local and remote computers;
- setup actions on emergency service restore in case of failure, for example auto service or computer restart (only on computers with Windows 2000 or later);
- create for services other names and descriptions, to find them easier (only on computers with system Windows 2000 or later);
- run service before user login (password input);
- service can be setup on automatic start after operation system load.

Note: you must be logged in as an administrator in order to change the configuration or control the service in any way (start, stop, pause, continue).

To on program work mode in service mode go to program options tab "Main menu -> Options -> Configure... -> Windows NT/2000/XP service" (pic.1), then put check box "Use program as service".



Pic.1 Service setting.

After that in the displayed window setup program run type. There can be the following variants:

1. Automat - service will be run automatically at every Windows start, before user login;


2. Manual - to run service make start in window "Services" of Control panel;
3. Disabled - service can't be run.

If you want to change program settings in service work mode, show "Display program window at service start". In that case at start service puts its icon in systray (pic.2). But then you couldn't use command "User logoff" in work stop select mode menu, so as in that mode Windows will wait manual service stop.



Pic.2 Service icon in systray.

If you use data bases or special COM port drivers, before service run, these applications must be run. You can show what services COM before DNC Precision in window "Start service after selected services" (pic.1). After you installed service mode for program, reload computer or run service manual from window "Services" in Control panel (pic.3)



Pic.3 Manual service run (in Windows 2000).

After service run in process list will be two applications dnpsrv.exe and dnpprecise.exe (pic.4). DNC Precision application makes interface between service manager and main DNC Precision

program and proper start and program stop. Unlike utility `srvany.exe` our service at stop saves all settings and completes all opened serial port session.

Name	CPU	Memory	Disk	Network
COM Surrogate	0%	5.7 MB	0 MB/s	0 Mbps
COM Surrogate	0%	3.0 MB	0 MB/s	0 Mbps
COM Surrogate	0%	3.4 MB	0 MB/s	0 Mbps
Cortana	0%	56.5 MB	0 MB/s	0.1 Mbps
Cortana Background Task Host	0%	5.1 MB	0 MB/s	0 Mbps
DNC Precision - Manage multip...	0%	0.7 MB	0 MB/s	0 Mbps
DNC Precision - send and recei...	0%	10.6 MB	0 MB/s	0 Mbps
Host Process for Windows Tasks	0%	4.1 MB	0 MB/s	0 Mbps
Microsoft Compatibility Teleme...	1.1%	8.4 MB	1.0 MB/s	0 Mbps
Microsoft Distributed Transacti...	0%	1.9 MB	0 MB/s	0 Mbps
Microsoft Malware Protection C...	0%	1.4 MB	0 MB/s	0 Mbps

Pic.4 Process list.

To have the program work in service mode it must be run with administrator rights. To control service manual and remove service, use command string. Run `dnpcsrv.exe` with the following parameters:

- `/?` - short help;
- `/I` - install service for start in manual mode;
- `/A` - install service for start in automatic mode;
- `/D` - install service in off state;
- `/R` - remove service from computer.

At once can be set only one parameter. At showing parameter keep characters register.

5 Sending files from other applications

Our software has a built-in DDE server. You can use this server to transfer files from other applications.

The following Windows registry entry can help you to detect a DNC Precision location:

```
SOFTWARE\Microsoft\Windows\CurrentVersion\Uninstall\DNC Precision_is1,  
Value: Inno Setup: App Path
```

The following Windows registry entry can help you to detect configured machines:

```
SOFTWARE\AGG Software\DNC Precision\Machines
```

You can search a running instance of DNC Precision by the class name "TfrmDNCPrecise" (w/o quotes).

The following code allows to detect, that application is started, all settings was loaded and program is initialized.

```
DNCP_IsStarted_Message = WM_USER+0x313;  
SendMessageTimeout(windowHandle, DNCP_IsStarted_Message, 0, 0, SMTO_NORMAL, 300,  
msg_res);
```

Result: msg_res>0 - if all is ok.

DDE interface

DDE server parameters:

Service: dncprecise
Topic: DNCPDDEServer

Poke the string value "%d||SEND||%d||%s" (w/o quotes) to the DDE item "Commands", where

1. %d - DDE client identification number
2. SEND - command name
3. %d - machine index (zero based)
4. %s - file name with full path to a NC program file

If you'll wait a transfer status, then sometimes sends the following Windows message:

```
DNCP_GetState_Message = WM_USER+0x314;
```

```
if ( !SendMessageTimeout(windowHandle, DNCP_GetState_Message, 0, 0, SMTO_NORMAL, 300,  
msg_res) )  
{  
    msg_res = 0x80000000;  
}  
Flag1 = msg_res & 0x80000000;
```

```
Flag2 = msg_res & 0x40000000;  
transferred_bytes = msg_res & $3FFFFFFF; // number of transferred bytes
```

if Flag1 isn't set then transfer is completed/terminated
if Flag2 is changing then the DNCP is transferring file

if the transfer is completed/terminated then you can request status string from the "Status" item.
This DDE item return a pointer to a status string:

%d||%s, where

%d - status code

%s - status message

6 Troubleshooting

6.1 No data received on CNC side

***Problem:** When trying to send data from the DNC to CNC, no data is received.*

Check the port log

If no data is sent because the file is empty or not exists, then the machine log file might give you some indication of what is wrong. For this feature you need enable log message in the machine options. Then select machine from list in the main window and now you can see log at the bottom of window.

Check the log combo box to verify that the server is actually sending any data. If no data is send, check the port status, in some cases the server will wait for a *start of transmission* signal from the CNC, if this is the case, the port status will indicate this.

Check that you are using the correct serial port

Open the configuration dialog, and check that you have selected the correct serial port.

Handshake problem

Check that you are using the correct handshake method. If hardware handshake is not enabled, try selecting **Set RTS high** and/or **Set DTR high** in the serial port configuration dialog. Some machines use non-standard software handshake characters. If this is the case change the **XOn character** / **XOff character** in the serial port configuration dialog. For further information, please refer to [Serial port](#).

The CNC needs a transmission start character

Some machines need a specific character before it starts to store a file. Check the machine manual. Many machines need a % at the top of the program, some need nulls (blank tape), others need an end of block code (CR/LF). If this is the case, you should specify this in the **Program start** field in the configuration dialog. For further information, please refer to [Program format](#).

Cycle start problem

Many machines require the program to be sent to them as soon as the cycle start button is pressed. Select transmit program at the DNC before pressing cycle start. This requires the PC to start sending when it either sees the handshake line going high (for hardware handshaking) or when it

receives an XOn (for software handshaking). If software handshaking is used then try enabling **Wait for XOn before send data** in the port transmit settings. For further information, please refer to [Program format](#).

Check your cable

Check that your cable is wired correctly. For information on how to wire a standard serial cable, please refer to [Serial communication overview](#). Some machines requires a special non-standard serial cable. For further information, please refer to the reference manual for your CNC.

Try another serial port

Try using another serial port, in case you have a defective serial port.

6.2 No data received on DNC server side

***Problem:** When trying to send data from the CNC to DNC, no data is received.*

Check the port log

If no valid program name is found, then the port log might give you some indication of what is wrong. For this feature you need enable log message in the machine options. Then select machine from list in the main window and now you can see log at the bootom of window.

Check that you are using the correct serial port

Check the log combo box to verify that the server is actually receiving any data. If not, open the configuration dialog, and check that you have selected the correct serial port.

Handshake problem

Check that you are using the correct handshake method. If hardware handshake is not enabled, try selecting **Set RTS high** and/or **Set DTR high** in the serial port configuration options tab. Some machines use non-standard software handshake characters. If this is the case change the **XOn character** / **XOff character** in the serial port configuration dialog. For further information, please refer to [Serial port](#).

6.3 Garbled data received

***Problem:** When trying to send data between the DNC and the CNC, the received data is garbled.*

This is most likely caused by incorrect baud or data bits settings.

Check that you are using the correct baud rate

Refer to your CNC's manual for further information.

Check that you are using the correct number of data bits

Refer to your CNC's manual for further information.

Check that you are using the correct number of stop bits

Refer to your CNC's manual for further information.

Machine is using EIA code

Set machine to ASCII/ISO, or select EIA in the port configuration. Refer to your CNC's manual for further information.

6.4 Data received as one long line

Problem: When trying to send data between the DNC and the CNC, the data is received as one long line.

This is most likely caused by incorrect len end character character setting.

Send data from CNC

First enable binary log files. For further information, please refer to [Logging](#). Try to send data from the CNC to the DNC server, then look at a file (see this file at binary mode with any hex viewer), and see what the CNC sends a linefeed characters. When you have determined the correct line feed character(s), change the port configuration to match this. For further information, please refer to [Program format](#).

Machine is using EIA code

Set machine to ASCII/ISO. Refer to your CNC's manual for further information.